



Connection Diagram for HPS-120 (after Ver3.0)

1. TxD/RxD/GND




- The **Flow Control** shall be **None** at the HPS-120.

2. TxD/RxD/CTS/RTS/GND



- The **Flow Control** shall be **Hardware** at the HPS-120.
- The Flow Control applies between the HPS-120 and PC (not over the air).
- If you want to pass it over the air, set the flow control to DTR/DSR with this diagram.

3. TxD/RxD/DTR/DSR/GND



- The **Flow Control** shall be **DTR/DSR** at the HPS-120.
- The Flow Control applies end-to-end (over the air).
- If you want to use RTS/CTS and DTR/DSR, you should use this diagram.